

STEP BY STEP: Clear User Data

Turn Camera OFF

1. Hold the SHIFT, IN and OUT buttons down (all 3)
2. WHILE STILL HOLDING THE BUTTONS DOWN
 - a. Turn the camera ON
3. Continue holding the SHIFT, IN and OUT buttons
Until you see “Too Many Keys” on the display
4. Release the Shift, In and Out buttons.
5. You MUST CHECK and reset the user data:
DISK OPERATIONS -> DISK SETTINGS
 - a. UNIT ID
 - b. Use < or > to choose a value from 1 to 36
 - c. Press SET UNIT NUMBER button to set the new ID

SYSTEM / SETUP -> SAT

- d. CLIP NAME

SYSTEM / SETUP -> SAT -> SETUP

- e. CLIP Attributes
 - i. Load (ODK.ATR & CUSTOM.ATR)
- f. ATTRS SET AT:
 - i. **PAUSE** or **EOP**

RECORD / PLAYBACK -> PAUSE-RECORD

- g. PAUSE-RECORD: **ON**

AUDIO / VIDEO -> PROJECT

- h. MEDIA FILES
 - i. **OMF** or **MXF**